

3TAAAFKP009A

PTO Clutch Relief Valve

The PTO clutch relief valve is provided to control the PTO operating pressure. When the oil pressure exceed the relief valve setting pressure, relief valve opens and the oil flows into PTO clutch and hydrostatic transmission.

(Reference)


- Relief valve setting pressure : 490 kPa
5.0 kgf/cm²
71.2 psi

- (1) Plug
- (2) O-ring
- (3) Spring
- (4) Steel Ball
- (5) PTO Clutch Valve
- (6) HST Charge Relief Valve
- (7) PTO Clutch Relief Valve
- (8) Poppet

- A : From Power Steering Controller
- B : To Hydrostatic Transmission
- C : To PTO Clutch Valve

- (a) Old Type
- (b) New Type

W1015382



3TAAAFKP012A

PTO Clutch "Engaged"

The oil from power steering controller flows into the PTO clutch valve.

When the PTO clutch lever is set at the "Engaged" position, the PTO clutch valve rotates. Oil flows from the oil line through transmission case to the PTO clutch pack.

Oil entering the clutch pack pushes the clutch piston (4) to engage the clutch pack. Power is transmitted from the HST pump shaft (1) through the PTO clutch to the clutch gear (2) and the PTO shafts.

- (1) HST Pump Shaft
- (2) Clutch Gear
- (3) Clutch Case
- (4) Clutch Piston
- (5) Clutch Plate
- (6) Clutch Disc
- (7) Spring
- (8) Spline Boss
- (9) O-ring
- (10) Transaxle Case
- (11) Brake Disc
- A : From PTO Clutch Valve
- B : Power to PTO Shaft
- C : PTO Clutch "Engaged"

W1015610