




2. STARTING SYSTEM



- | | | | |
|--------------------|-------------------|---------------------|---------------------------------|
| (1) Battery | (6) Starter Relay | (10) Glow Plug | (14) Relay 1 |
| (2) Slow Blow Fuse | (7) Starter Motor | (11) PTO Relay | (15) Timer Relay |
| (3) Fuse (20 A) | (8) Diode | (12) PTO Switch | (16) Engine Oil Pressure Switch |
| (4) Main Switch | (9) Glow Relay | (13) Key Stop Relay | (17) Fuel Cut-off Solenoid |
| (5) Safety Switch | | | |



There are four key positions, **OFF**, **ON**, **PREHEAT (GLOW)**, and **START**.

When the main switch is set to **PREHEAT (GLOW)**, **B** terminal of the main switch is connected to **G** and **AC (M)** terminals. Consequently, battery current flows to coil **C3** of the glow relay (9), and the relay contact point **S4** is turned on. This makes the glow plugs red-hot.

When the main switch (4) is set to **START** under the condition that the range gear shift lever is in neutral position and the safety switch (5) is turned on and PTO clutch lever is in **OFF** position (PTO switch (12) is **ON**).

B terminal of the main switch is connected **G**, **ST** and **AC (M)** terminals.

Consequently, battery current flows to coil **C1** of the starter relay (6) and PTO relay (11) contact point **S3** of the PTO relay (11) (When the PTO switch is set to **ON**, battery current flows to coil **C2** and **S5** is turned to **ON**.) and coil **C3** of the glow plug relay at the same time, and relay contact points **S1** and **S4** are turned on.

This actuates starter motor (7) and keeps the glow plugs red-hot.

At this time, battery current flows to coil **C5** of the relay 1 (14) and relay contact point **S7** is turned on.

Battery current flows to pull-in coil and holding coil of fuel cut-off solenoid (17) to pull the plunger at engine starting position.

When the main switch is released after starting the engine, the main switch returns to **ON** automatically.

W1012830