
Starboard Loader Ram
Starboard Bucket Ram
PB
Loader Controls
Open
These disconnects attached to loader frame
Open
PB
Aux Control 1
Starboard Stabilizer
Swing Ram
Pump
Storage Tank (Vented)
Hoe Control
Open
Boom Main
Boom Arm
Bucket Ram
PB
Open
Aux Control 2
Disconnect attached to Hoe Controls
Connection must be moved to Aux Control 1 PB out connector if Hoe disconnected from Loader
Port Stabilizer
Port Bucket Ram
Port Loader Ram