

Item	Part No.	Description	Book
ENGINE	01G001	CRANKCASE	100K0182
	01G002	OIL PAN	100K0182
	01G003	PISTON/CRANKSHAFT	100K0182
	01G004	MAIN BEARING CASE	100K0182
	01G005	FLYWHEEL	100K0182
	01G006	CYLINDER HEAD	100K0182
	01G007	VALVE/ROCKER ARM	100K0182
	01G008	NOZZLE HOLDER/GLOW PLUG	100K0182
	01G009	NOZZLE HOLDER [COMPONENT PARTS]	100K0182
	01G010	HEAD COVER	100K0182
	01G011	INLET MANIFOLD	100K0182
	01G013	EXHAUST MANIFOLD	100K0182
	01G015	CAMSHAFT	100K0182
	01G016	GEAR CASE	100K0182
	01G017	WATER PUMP	100K0182
	01G018	WATER FLANGE/THERMOSTAT	100K0182
	01G019	INJECTION PUMP	100K0182
	01G020	INJECTION PUMP [COMPONENT PARTS]	100K0182
	01G021	SPEED CONTROL PLATE	100K0182
	01G022	GOVERNOR	100K0182
	01G023	STOP SOLENOID	100K0182
	01G024	UPPER GASKET KIT	100K0182
	01G025	LOWER GASKET KIT	100K0182
	02G012	AIR CLEANER	100K0182
	02G014	MUFFLER	100K0182
	02G026	ACCELERATOR LEVER	100K0182
FUEL SYSTEM	02G052	FUEL TANK	100K0182
COOLING WATER SYSTEM	02G053	FUEL PIPE	100K0182
	02G055	RADIATOR	100K0182
ELECTRICAL SYSTEM	02G056	FAN	100K0182
	02G057	DYNAMO	100K0182
	02G058	DYNAMO [COMPONENT PARTS]	100K0182
	02G059	STARTER [COMPONENT PARTS]	100K0182
	02G060	STARTER [COMPONENT PARTS]	100K0182
	02G062	BATTERY	100K0182
	02G064	LIGHT	100K0182
	02G065	DASHBOARD	100K0182
	02G066	DASHBOARD	100K0182
	02G068	WIRE HARNESS	100K0182
TRANSMISSION	02G070	TRANSMISSION CASE	100K0182
	02G071	HST	100K0182
	02G072	HST [COMPONENT PARTS]	100K0182
	02G073	UNIVERSAL JOINT/HST FAN	100K0182
	02G074	UNIVERSAL JOINT/HST FAN	100K0182
	02G075	PTO SHAFT	100K0182
	02G076	TENSION PULLEY	100K0182
	02G077	BELT RETAINER	100K0182
	02G078	REAR PTO	100K0182
	02G079	REAR PTO [COMPONENT PARTS]	100K0182
SPEED CHANGE	02G080	CRUISE CONTROL PLATE	100K0182
	02G081	CRUISE CONTROL LEVER	100K0182
	02G082	SPEED CONTROL PEDAL	100K0182
REAR AXLE	02G083	REAR DIFFERENTIAL	100K0182
	02G084	REAR AXLE CASE	100K0182
	02G087	REAR AXLE [4WS]	100K0182
	02G088	REAR AXLE JOINT [4WS]	100K0182
	02G089	KNUCKLE ARM [4WS]	100K0182

Item	Part No.	Description	Book
REAR AXLE	02G090	TIE ROD [4WS]	100K0182
	02G091	DRAG LINK [4WS]	100K0182
BRAKE	02G092	REAR WHEEL (23 X 8.50-12) [4WS]	100K0182
	02G093	PTO BRAKE	100K0182
	02G094	BRAKE SHAFT	100K0182
	02G095	BRAKE	100K0182
	02G096	BRAKE ROD	100K0182
FRONT AXLE	02G097	BRAKE PEDAL	100K0182
	02G098	FRONT AXLE/KNUCKLE ARM	100K0182
	02G099	TIE ROD/DRAG LINK	100K0182
	02G100	FRONT WHEEL (16 X 6.50-8)	100K0182
STEERING	02G101	FRAME	100K0182
	02G102	STEERING GEAR CASE	100K0182
HYDRAULIC SYSTEM	02G103	STEERING WHEEL	100K0182
	02G104	CONTROL VALVE	100K0182
	02G105	CONTROL VALVE [COMPONENT PARTS]	100K0182
	02G106	HYDRAULIC PIPE 1	100K0182
	02G107	HYDRAULIC PIPE 2	100K0182
	02G108	LIFT CYLINDER	100K0182
	02G109	HYDRAULIC OUTLET [OLD TYPE] [OPTION]	100K0182
	02G110	HYDRAULIC OUTLET [NEW TYPE] [OPTION]	100K0182
	02G111	3-POINT LINKAGE [OPTION]	100K0182
	02G112	MOWER ASSIST SPRING [OPTION]	100K0182
BONNET/HOOD/CHASSIS	02G113	MOWER SWING STOPPER [OPTION]	100K0182
	02G114	HOOD (BONNET)	100K0182
	02G115	PANEL	100K0182
	02G116	FENDER	100K0182
	02G117	SEAT [A] [CA]	100K0182
LABELS	02G118	SEAT [AU] [NZ]	100K0182
	02G119	LABEL	100K0182
ACCESSORIES	02G145	ACCESSORIES AND SERVICE PARTS	100K0182