

MAINTENANCE

SERVICE INTERVALS

No.	Items		Indication on hour meter															Interval	Ref page		
			50	100	150	200	250	300	350	400	450	500	550	600	650	700	800				
1	Clogging of air conditioner condenser screen	Clean																Daily	70		
2	Engine oil	Change	⊙			○				○				○			○	every 200 Hr	79		
3	Engine oil filter	Replace	⊙			○				○				○			○	every 200 Hr	78		
4	Transmission oil filters [HST]	Replace	⊙			○				○				○			○	every 200 Hr	79		
5	Hydraulic oil filter	Replace	⊙							○							○	every 400 Hr	85		
6	Transmission fluid	Change								○							○	every 400 Hr	84		
7	Front axle case oil	Change								○							○	every 400 Hr	86		
8	Front axle pivot	Adjust								○							○	every 400 Hr	86		
9	Engine start system	Check	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	every 50 Hr	72		
10	Greasing	-	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	every 50 Hr	72		
11	Wheel bolt torque	Check	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	every 50 Hr	73		
12	Battery condition	Check		○		○		○		○		○		○		○	○	every 100 Hr	73	*5	
13	Air cleaner element [Double element type] Primary element	Clean		○		○		○		○		○		○		○	○	every 100 Hr	75	*1	Ⓢ
		Replace																every 1 year	86	*2	
	Air cleaner element [Double element type] Secondary element	Replace																every 1 year	86		
14	Fuel filter element	Clean		○		○		○		○		○		○		○	○	every 100 Hr	76		Ⓢ
		Replace								○							○	every 400 Hr	86		
15	Fan belt	Adjust		○		○		○		○		○		○		○	○	every 100 Hr	77		