



0107F025

### Engine Oil Flow

- (1) Oil Pan
- (2) Oil Strainer
- (3) Oil Pump
- (4) Relief Valve
- (5) Oil Filter Cartridge
- (6) Idle Gear
- (7) Main Oil Gallery
- (8) Main Bearing
- (9) Big End
- (10) Timing Gear
- (11) Splash
- (12) Bore
- (13) Small End
- (14) Piston
- (15) Fuel Camshaft
- (16) Tappets
- (17) Camshaft Bearing
- (18) Camshaft
- (19) Drain
- (20) Rocker Arm
- (21) Oil Switch
- (22) Rocker Arm Shaft

### Circuit d'huile

- (1) Carter d'huile
- (2) Crépine
- (3) Pompe à huile
- (4) Soupape de décharge
- (5) Cartouche de filtre à huile
- (6) Pignon de renvoi
- (7) Rampe de distribution d'huile
- (8) Palier principal
- (9) Tête de bielle
- (10) Pignon de distribution
- (11) Eclaboussement
- (12) Alésage
- (13) Pied de bielle
- (14) Piston
- (15) Arbre à cames d'alimentation
- (16) Pousoirs
- (17) Paliers d'arbre à cames
- (18) Arbre à cames
- (19) Retour
- (20) Culbuteur
- (21) Manoccontact de pression d'huile
- (22) Arbre de culbuteur

## Motorölstrom

- (1) Ölwanne
- (2) Ölfilter
- (3) Ölpumpe
- (4) Überdruckventil
- (5) Ölfilterpatrone
- (6) Leerlaufgetriebe
- (7) Hauptölkanal
- (8) Hauptlager
- (9) Pleuelstangenfuß
- (10) Steuerung
- (11) Ölspritzer
- (12) Bohrung
- (13) Pleuelstangenkopf
- (14) Kolben
- (15) Kraftstoff-Nockenwelle
- (16) Stößel
- (17) Nockenwellenlager
- (18) Nockenwelle
- (19) Ablauf
- (20) Kipphebel
- (21) Ölschalter
- (22) Kipphebelachse