


[2]-2 L2350 4WD TYPE

• Main Switch Table

Terminal	B	AC	G1	G2	ST	OFF
Key Position						
OFF	●					●
ON	●	●				
HEAT	●	●	●			
START	●	●		●	●	

• Combination Switch

Head light switch					Hazard light switch		
Color	RW	Y	Br	OR	Color	G	GW
	B1	T	1	2		B2	R
OFF					1	●	●
1	●	●	●		OFF		
2	●	●		●	2	●	●



B122F047

- Denotes battery voltage at any position of main switch
- Denotes battery voltage when turning on main switch "ON" position from "OFF" position.
- Denotes ground line.