

LUBRICANTS, FUEL AND COOLANT

No.	Locations		Capacities	Lubricants	
			L2501		
1	Fuel		38.0 L (10.0 U.S.gals.)	No. 2-D diesel fuel No. 1-D diesel fuel if temperature is below -10 °C(14 °F)	
2	Coolant		6.0 L (6.3 U.S.qts.)	Fresh clean soft water with anti-freeze	
3	Engine crankcase (with filter)		5.7 L (6.0 U.S.qts.)	• Engine oil : Refer to next page	
				Above 25°C (77°F)	SAE30, SAE10W-30 or 15W-40
				-10°C to 25°C (14 to 77°F)	SAE20, SAE10W-30 or 15W-40
				Below -10°C (14°F)	SAE10W-30
4	Transmission case	Manual Transmission, 2WD	27.0 L (7.1 U.S. gals.)	• KUBOTA SUPER UDT-2 fluid	
		Manual Transmission, 4WD	27.5 L (7.3 U.S. gals.)		
		HST, 4WD	23.5 L (6.2 U.S. gals.)		
5	Front axle case [4WD]		4.5 L (4.8 U.S.qts.)	• KUBOTA SUPER UDT-2 fluid or SAE 80 - SAE 90 gear oil	
6	Greasing		No. of greasing points	Capacity	Type of grease
	• Front wheel hub		2 [2WD only]	A small amount	Bearing grease
	• Knuckle shaft		2 [2WD only]	Until grease overflows.	Multipurpose Grease NLGI-2 OR NLGI-1 (GC-LB)
	• Front axle support		2 [4WD only]		
	• Clutch pedal		1		
	• Brake pedal		1		
	• Pedal shaft		1		
	• Battery terminals		2		
	• Lift rod		1		
	• Tie rod end		4 [4WD only]		

NOTE :

The product name of KUBOTA genuine UDT fluid may be different from that in the Operator's Manual depending on countries or territories. Consult your local KUBOTA Dealer for further details.